

Dispersion suppressor (Section 3.7.7)

Volker Ziemann, 211119

In this example we illustrate the code that generated Figure 3.30 with the dispersion suppressor in a 90-degree FODO lattice. The suppressor consists of two FODO cells where the full-length dipole magnets are replaced by half-length dipoles.

First we need to add support for the 3D calculations...

```
clear all
addpath ./3D      % contains the support functions, such as calcmat()
```

...and define the regular FODO cells that are used in the arcs.

```
fodo=[           % regular FODO cell in arc
    2,    1,    0,    8.5511;
    1,    5,    0.2,    0;
    4,    8,    0.5,    1;    % 8x0.5m = 4 m long dipole
    1,    5,    0.2,    0;
    2,    1,    0,   -4.2483;
    1,    5,    0.2,    0;
    4,    8,    0.5,    1;    % 4 m long dipole
    1,    5,    0.2,    0;
    2,    1,    0,    8.5511];
```

The FODO cell in the disp[ersion suppressor is very similar, only the dipoles are shorter and the adjacent drift spaces are a bit longer in order to maintain the length of the cell. Note also that the quadrupoles excitations are the same in both types of cells.


```
fodods=[         % FODO cell in dispersion suppressor
    2,    1,    0,    8.5511;
    1, 10,    0.2,    0;
    4,    4,    0.5,    1;    % 4x0.5m = 2 m long dipole
    1, 10,    0.2,    0;
    2,    1,    0,   -4.2483;
    1, 10,    0.2,    0;
    4,    4,    0.5,    1;    % 2 m long dipole
    1, 10,    0.2,    0;
    2,    1,    0,    8.5511];
```

Now we calculate the periodic dispersion in an arc cell, which give us the initial value D_0 for the dispersion that causes a periodic dispersion in the arcs.

```
beamline=fodo;    % one arc-fodo cell
[Racc,spos]=calcmat(beamline);
Rend=Racc(:,:,end);
D0=periodic_dispersion(Rend);
```

In order to verify that the dispersion is periodic we plot it

```
D=calculate_dispersion(beamline,D0);
plot(spos,D,'k');
xlabel(' s[m]'); ylabel('D_x [m]');
drawmag(beamline,0.2,0.2)
title('Dispersion in one arc cell')
```




Now we add two dispersion suppressor cells to one arc cell and calculate all transfer matrices and the positions spos with calcmat().

```
beamline=[fodo;repmat(fodods,2,1)]; % one arc and two suppressor cells
[Racc,spos]=calcmat(beamline);
```

Finally, we calculate the dispersion D along the beam line and plot it. For convenience, we also add the magnet lattice to show the positions of the dipoles and their respective lengths.

```
D=calculate_dispersion(beamline,D0);
figure; plot(spos,D,'k'); % Fig. 3.30
xlabel(' s[m]'); ylabel('D_x [m]');
title('Dispersion suppressor')
drawmag(beamline,0.2,0.2)
xlim([0,36.1]);
```



Note that the dispersion is not perfectly zero at the end, because weak focussing of the dipoles which is slightly different for the full-length and half-length dipoles. This can be fixed by slightly changing the quadrupole excitations.